

Corniche Desk Assembly Instructions

RECTANGULAR/WAVE DESK

SCREW 2 PINS
INTO EACH PANEL
END

INSERT 2 SMALL CAMS
EACH END OF BACK
PANEL. MAKE SURE
ARROW ON CAM
POINTS TOWARD END
OF PANEL

SCREW 2 SMALL
BRACKETS TO BACK
PANEL AND TOP. USE
PILOT HOLES AND
SCREWS PROVIDED.

INSERT 4 LARGE
CAMS INTO EACH
PANEL END. MAKE
SURE ARROW ON CAM
POINTS DOWNWARD

SCREW 4 PINS
INTO EACH END OF
DESK TOP

STEPS

1. MAKE SURE TOP IS ON PROTECTIVE SURFACE TO AVOID DAMAGE TO VENEER.
2. INSERT CAMS INTO BACK PANEL AND PANEL ENDS AS SHOWN.
3. ASSEMBLE PANEL ENDS AND BACK PANELS FIRST. TIGHTEN CAMS IN BACK PANELS.
4. SCREW PINS INTO INSERTS IN TOP.
5. LOCATE PANEL ENDS ONTO PINS IN TOP. TIGHTEN CAMS IN PANEL ENDS.
6. FIX BRACKETS TO BACK PANEL USING PILOT HOLES AND SCREWS PROVIDED.
7. INVERT DESK.

CRESCENT DESKS

