

IDENTIFY WHICH DESK YOUR DDA UNIT IS TO FIX TO, AND PREPARE THE RECTANGULAR INFILL PANEL AND BRACKETS SUPPLIED



OFFER UP THE INFILL PANEL TO THE END PANEL OF THE DESK, ENSURING AN EVEN BREAK (2mm) FRONT AND BACK. USE THIS INFILL PANEL AS A JIG TO POSITION THE BRACKETS ON THE DESK.



THE BRACKET SHOULD BE PUSHED TO THE UNDERSIDE TO THE TOP AND BE CENTRED ON THE SLOT. FIX THE **BRACKET** ONLY TO THE PANEL LEG.

REMOVE THE INFILL PANEL WHICH YOU HAVE USED AS A JIG.



OFFER UP THE INFILL PANEL TO YOU DDA UNIT, ENSURING THAT THERE IS AN EVEN BREAK (2MM) FRONT AND BACK. FIX THE PANEL TO THE DDA UNIT



YOU ARE NOW READY TO JOIN THE DESK TO THE DDA UNIT.

PUSH THE TWO UNITS TOGETHER SO THAT THE BRACKETS PUSH THROUGH THE SLOTS IN THE INFILL PANEL AND LEG. ENSURE THAT THE UNITS ARE LEVEL AND FLUSH FRONT AND BACK BEFORE FIXING THE BRACKET INTO THE UNDERSIDE OF THE DDA TOP.



OCDA0808 ASSEMBLY INSTRUCTIONS