


VERCO

2 Smart + E2 Smart


Operating
Instructions





arm height

rotate knob clockwise, gradually lift arm rest to the desired height. release knob to lock.



seat height

push button and use body weight to raise or lower the seat to desired position, release button to lock.

seat activator

push button in to release, use body weight to activate seat. depress button to lock in one of 3 positions

congratulations on purchasing your new 'intelligent' chair

The 'smart' mechanism automatically senses your body weight as you sit on the chair and intuitively provides the correct tension to work in harmony with your body, and ensures that the flexible backs fit naturally into the curve of your spine...

...resulting in a simple seat adjustment as the only critical adjustment you will need to make.

Leaving you more time to enjoy the comfort of your new 'smart' chair

care advice

Please regularly check that your chair's components are complete and in good working order and ensure that the chair is structurally sound and functioning properly.

Plastic components should be wiped with a soft cloth soaked in mild detergent and warm water. Rinse thoroughly and dry with a soft cloth.

In order to maintain the fabric over the five year guarantee period, the upholstery must be cleaned and vacuumed on a regular basis.

Please visit www.verco.co.uk for further information.

VERCO
OFFICE FURNITURE LIMITED

www.verco.co.uk