




# Zenith

Operating Instructions

# swivel and tilt action







## swivel and tilt action

pull out lever to release action, lean backwards or forwards to achieve desired position, pull lever in to lock. for 'dynamic posture' the chair may be left unlocked in it's 'free float' mode.

the action has a safety feature. when the action is first unlocked, lean against back to start the action.

#### seat height

lift lever and use body weight to raise or lower the seat to desired position, release lever to lock.

#### tension control

to adjust the tension of the action, turn knob clockwise to increase and anti-clockwise to decrease tension.

### knee tilt action

lift lever to release action, lean backwards or forwards to achieve desired position, push lever down to lock. for 'dynamic posture' the chair may be left unlocked in it's 'free float' mode.

the action has a safety feature. when the action is first unlocked, lean against back to start the action.

# Zenith Knee Tilt Action

## care advice

Please regularly check that your chair's components are complete and in good working order and ensure that the chair is structurally sound and functioning properly.

Plastic components should be wiped with a soft cloth soaked in mild detergent and warm water. Rinse thoroughly and dry with a soft cloth.

In order to maintain the fabric over the five year guarantee period, the upholstery must be cleaned and vacuumed on a regular basis.

Please visit www.verco.co.uk for further information.

