

mesh

operating instructions



permanent contact back action





back angle

Lift lever to release action, lean backwards or forwards to achieve desired position, push lever down to lock. For 'dynamic posture' the chair may be left unlocked in its 'free float' mode.

The action has a safety feature. When the action is first unlocked, lean against back to start the action.

tension control

To decrease the tension of the action, turn wheel clockwise. Turn the wheel anti-clockwise to increase tension.

lumbar support

Place hands above and below the lumbar support, gradually raise or lower to desired height.

headrest height

Hold headrest with both hands, gradually raise or lower to desired height.

synchro action

Lift lever to release action, lean backwards or forwards to achieve desired position, push lever down to lock. For 'dynamic posture' the chair may be left unlocked in its 'free float' mode.

The action has a safety feature. When the action is first unlocked, lean against back to start the action.

Lift lever and use body weight to raise or lower the seat to desired position, release lever to lock.

seat height

seat depth

Lift lever to release seat, use body weight to slide seat to desired position, release lever to lock.

arm height

Push button on inside of arm and raise or lower arm to the desired height, release button to lock.

Please note: depending on the specification of your chair it may not have all of the featured options above.

care advice

Please regularly check that your chair's components are complete and in good working order and ensure that the chair is structurally sound and functioning properly.

Plastic components should be wiped with a soft cloth soaked in mild detergent and warm water. Rinse thoroughly and dry with a soft cloth.

In order to maintain the fabric over the five year guarantee period, the upholstery must be cleaned and vacuumed on a regular basis.

Please visit www.verco.co.uk for further information.





www.verco.co.uk